

# **METOS THERMOBOX**

# USERMANUAL

## Starting the product

• Hold the power button (1) until the display shows "ON". The display shows the current temperature.

#### Setpoint

- Press and hold the "SET" button (3) until the set point is displayed (80°C). Change the value with the up or down arrow (4).
- To save the change, hold the "SET" button (3).

## **Closed use**

• Hold the power button (1) until the display (2) shows "OFF". The display flashes between current temperature and "OFF".

#### If the equipment is not used

• Disconnect the power and control current to the product by the main power switch or in the resort's center



- 1. Switch
- 2. Display
- 3. "SET" button
- 4. Up and down arrows

