







1. Electrical connection: fixed
2. Cold water connection/filter R1/2" 250-600 kPa 11 l/min.
3. Hot water connection/filter R1/2" 100-600 kPa
4. Drain connection Ø50
5. Steam connection R3/4" (333-423 R1") 150-250 kPa
6. Condens water connection R3/4"
7. Sink 3l/sek.
8. Exhaust heat recovery unit
9. Alternative electrical connection
10. Alternative cold water connection R1/2" 250-600 kPa 11 l/min
11. Alternative hot water connection R1/2" 100-600kPa
12. Alternative drain connection Ø50
13. Non return valve
14. Vacuum valve
15. Output detergent dosing
16. Main switch
17. Service clearance

#### Marine foot plate installation

1. Remove the plastic plug from the dishwasher leg.
2. Put the marine footplate in and adjust the leg to the right height.
3. Drill a hole through the center of the leg and footplate and fix them together with M10 bolt.



| Code      | Electric supply  | P/kW | Fuse/A |
|-----------|------------------|------|--------|
| 4246276MM | 3PE AC 440V 60Hz | 32,6 | 50     |
| 4246275MK | 3PE AC 400V 50Hz | 32,6 | 50     |

|                                                                                                                                                                                                                                                                                                          |                    |                                               |                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------------------------------------|-----------------|
| Vers.                                                                                                                                                                                                                                                                                                    | Muutos:            | Pvm.                                          | Suun.           |
| Tämä piirustus on Metos Oy Ab:n omaisuutta, kopiointi tai osittainenkin jäljentäminen ilman Metos Oy Ab:n lupaa on ehdottomasti kielletty.<br>This document may not be copied in part or in whole by any process nor passed on to a third party without the written permission of the owner Metos Oy Ab. |                    |                                               |                 |
| Suun.                                                                                                                                                                                                                                                                                                    | Kaupalliset asiat: | Työmaa-asiat:                                 |                 |
| <a href="http://www.metos.com">www.metos.com</a><br>Suhde: 1: 30 A4                                                                                                                                                                                                                                      | Proj.no            | Tarj./lausnro.                                | Pvm. 08.12.2023 |
|                                                                                                                                                                                                                     |                    | Rack conveyor machine METOS WD-151E TOUCH L-R |                 |
| Metos Oy Ab<br>FI-04220 KERAVA<br>Tel: 0204 39 13 Fax: 0204 39 4432                                                                                                                                                                                                                                      |                    | Piiir.no<br>Lehti                             |                 |